



LUMIDEE
stay connected

QUICK START GUIDE


Yealink W70B

Heeft u vragen?
bel naar: [073 - 751 77 77](tel:073-7517777) of
mail naar: support@lumidee.nl




Controle

Controleer de verpakkingen of alle bestelde producten aanwezig zijn:
Basisstation W70B
4G Router (indien besteld)
Headset(s)
Multi Unit Charger (indien besteld)
Handset (indien besteld)




Basisstation W70B

Haal de W70B basisstation en de meegeleverde stekker uit de verpakking. Sluit de stekkerkabel aan op de achterkant van het basisstation (1). Steek vervolgens de stekker in het stopcontact. Hang het basisstation zo hoog en centraal mogelijk op.




4G Router

Schroef de 3 antennes op de router: 2 op Mobile (1), 1 op WiFi (2). Sluit de stekkerkabel met blokje met 4 pinnen (3) aan op de achterkant. Steek vervolgens de stekker in het stopcontact. Sluit de meegeleverde UTP kabel aan op LAN (4). En sluit deze kabel aan op de W70B in LAN aansluiting.



Headsets met meervoudige lader

Haal de headsets en multi unit charger uit de verpakking. Sluit de stekker aan op de achterkant van de multi unit charger. Steek vervolgens de stekker in het 220V stopcontact. Plaats de headsets in de multi unit charger en wacht 30 minuten. De headsets zijn klaar voor gebruik (of zie QSG WH62/WH63).



Handset(s)

Haal de handset en lader en de meegeleverde stekker uit de verpakking. Sluit de kabel op de achterkant van het basisstation. Stop de stekker in het stopcontact. Zet de handset in basisstation. Wacht 30 minuten. Neem de handset uit het basisstation. De handset is klaar voor gebruik (of zie QSG W59R).



LUMIDEE

stay connected

QUICK START GUIDE Yealink W70B

Questions?


Please call: [073 - 751 77 77](tel:073-751777)
or email: support@lumidee.nl



Checks


Check the packaging whether all ordered products are present:

- Base station W70B
- 4G Router (if ordered)
- Headsets
- Multi Unit Charger (if ordered)
- Handset (if ordered)




Base station W70B

Remove the W70B base station and the supplied plug from the packaging. Connect the plug cable to the back of the base station (1). Then put the plug into the 220V socket. Hang the base station as high and central as possible.




4G Router

Screw the 3 antennas onto the router: 2 on Mobile (1), 1 on WiFi (2). Connect the plug cable with the 4-pin block (3) into the back. Then put the plug into the 220V socket. Connect the supplied UTP cable to LAN (4). And connect this cable to the W70B in LAN connection.



Headsets with multi unit charger

Remove the headsets and multi unit charger from the packaging. Connect the plug to the back of the multi unit charger and then plug the other side of the cable into the 220V socket. Place the headset in the multi unit charger and wait 30 minutes. The headsets are ready for use (or see QSG WH62/WH63).



Handset(s)

Remove the handset and base station and power cable from the box. Connect the cable to the back of the base station. Then put the plug into the 220V socket. Place the handset in the base station. Charge for 30 minutes. Remove the handset from the base station. The handset is ready for use (or see QSG W59R).